

**DART****RELEASED**

02-12-05

PPP

Part Number **K10004**Description **Saddle Kit**Box Part Number **MBX104** Dimension **36 1/2**

L x W x H

Other Packaging  Dimension **MF1612**Logo Decals **N/A** **N/A****Packaging Instructions and Decal Placement****K10004**

Glue 2 pieces of MF1612 (one at each end). Place previously foamed saddles in box then add hardware. Close box and apply Dart Logo tape lengthwise, strap box twice at each end. Apply clear tape over strappings and staple (each end). Apply label D2729-3 as per instructions in QSI 014 section 4.5.

**NOTE: Fill all voids of box with foam to prevent movement.****D2729-1****N/A****D2729-3****DART**

**Dart Aerospace Ltd.**  
1270 Aberdeen Street  
Hawkesbury, ON K6A 1K7  
CANADA  
TEL.: 1 613 632-5200

**K10004 SADDLE KIT CHG005****INCLUDE PARTS FOR:****D412-652-011/-021****D205-594-011/-013/-015/-021/-023****B/N: BXXXXX**

Revision: **D E A** 08-09-23  
09.02.02 Date: 02-11-21 05-07-22  
H:\Admin-qa\iso\forms\PPP-1.Rev.A

09/02/03

02/10/03

02-12-04

05/08/07